



SCAN ME FOR INSTALLATION TUTORIALS & DOCUMENTATION





QUICK GUIDE HYD3000-HYD6000-ZP1 HYBRID INVERTER



Always wear protective clothing and/or personal protective equipment



Always consult the manual



General notice -Important Safety Instructions

TABLE OF CONTENTS

1. INSTALLATION AND DISTANCES 2. INSTALLATION **3. DISPLAY & BUTTONS** 4. MAIN MENU **5. CONNECTING TO THE GRID** 6. PHOTOVOLTAIC CONNECTIONS 7. COMMUNICATION CONNECTION - COM PORT 8. BATTERY CONNECTION 9.1 SETTING PHOTOVOLTAIC CHANNELS **9.2 SETTING BATTERY CHANNEL 10.1 MEASURING EXCHANGE VIA CT SENSOR** 10.2 MEASURING EXCHANGE VIA DDSU METER **10.2.1 DDSU METER SETTING ON EXCHANGE AND INVERTER 10.2.2 MEASURING EXTERNAL PRODUCTION VIA DDSU METER 10.2.3 DDSU METER SETTING ON EXTERNAL PRODUCTION 10.2.4 CONFIGURING DDSU EXCHANGE METER AND DDSU PRODUCTION METER 10.2.5 CHECKING CORRECT DDSU METER READING 10.3 READING VIA DDSU METER 10.3.1 SETTING DTSU METER 10.3.2 CHECKING CORRECT DTSU METER READING 11. INITIAL SET UP PROCEDURE 12. INITIAL SET-UP 13. CHECKING THE CORRECT OPERATION 14. CHECKING THE INVERTER SETTINGS 15. ZERO FEED-IN MODE** 16. LOGIC INTERFACE (DRMS0) 17.1 EPS MODE (OFF GRID) 17.2 EPS MODE (OFF GRID) - WIRING PROCEDURE AND INSTALLATION TYPES 17.3 EPS MODE (OFF GRID) - OPERATION 17.4 EPS MODE (OFF GRID) - MENU ENABLING **18.1 OFF GRID MODE ONLY** 18.2 OFF GRID MODE ONLY - START UP **19.1 PARALLEL INVERTER MODE - CONFIGURATION 19.2 PARALLEL INVERTER MODE - SETTINGS** 20. FIRMWARE UPDATE 21. SELF-TEST 22. % CHARGE MODE 23. QUICK INFO ON SYSTEM STATUS

24. OPERATING STATUSES IN AUTOMATIC MODE

1. INSTALLATION AND DISTANCES

Dimensions and distances to be observed:



To guarantee adequate room for both installation and effective heat dissipation, make sure there is ample space around the 1PH HYD3000-HYD6000-ZP1 residential energy storage inverter.



Installing the base:



Step 1: Place the base against a wall, leaving a gap of 10-25 mm between the base and the wall. Adjust the position of the holes using a level and mark them with a felt-tip pen.

Step 2: To install the base, remove it, and drill the holes using an impact drill with an 8 mm diameter bit, drilling to a depth of 60-65 mm. Tighten the expansion screws to firmly secure the base in place.

Step 3: Use a felt-tip pen to mark the holes for attaching the battery modules and inverters, following the dimensions shown in the figure below.

If holes cannot be drilled on the ground, the battery expansion modules must be secured on the wall

Installing the modules:



Step 1: Align the first battery module to the base.

Step 2: Install the connectors on both sides and tighten the six screws using a cross screwdriver.

Step 3: Install the remaining battery modules and inverter from bottom to top. (Before installing the next module, ensure that the screws on the side connectors of the previous module are firmly tightened).



Step 1: Use an impact drill (ϕ 8 mm, depth 60-65 mm) to drill the holes. Reposition and drill the holes in case of significant deviation.

Step 2: Install support panel B on the wall and fasten the expansion bolt.

Step 3: Adjust support panel A, making sure that the holes on both panel A and B are perfectly aligned.

Step 4: Connect and secure panel A and B using M6*16 screws.

Installing the cover:

After ensuring the correctness and reliability of the electrical connections, install the outer protective cover and secure it with the screws.





3. DISPLAY & BUTTONS



1	System power indicator	3	Button
2	System status indicator	4	LCD screen

System status		Indicator	
	Blue LED	Green LED	Red LED
On-Grid	On		
Standby (On-Grid)	Intermittent		
Off-Grid		On	
Alarm			Intermittent

lcon	Battery capacity
	80-100%
	60-80%
	40-60%
	20-40%
	0-20%

4. MAIN MENU



Today	Week	Month	Year	Life Cycle
PV prod.				
AutoCon	AutoCon	AutoCon	AutoCon	AutoCon
Export	Export	Export	Export	Export
Consumption	Consumption	Consumption	Consumption	Consumption
AutoCon	AutoCon	AutoCon	AutoCon	AutoCon
Import	Import	Import	Import	Import

5. CONNECTING TO THE GRID

Step 0: Select the suitable cable type and specifications.



Step 1: Thread the wire through the terminal.



Step 2: Align the wire with the marking, insert it into the hole on the terminal and tighten it.



Step 3: Push the terminal forward until a "click" is heard.



Step 4: Connect the attached load terminal to the inverter's load port and push the terminal forward until it clicks into place.



Item	Description		Recommended cable type	Recommended cable specification
		L (U)		
(26)	AC Grid	N (W)	Multi-core copper cable for outdoor use	Cross-section area of the conductor: 8 AWG
		PE (0)		
	LOAD	L (U)	Multi-core copper cable for outdoor use	
		N (W)		Cross-section area of the conductor: 8 AWG
		PE (O)		

6. PHOTOVOLTAIC CONNECTIONS Cross-sectional area (mm²) **Recommended specifications for** Outer cable area (mm²) Recommended **DC input cables** Range value 4.0~6.0 4.0 4.5~7.8 Prepare the positive and negative photovoltaic cables. 8-10 mm 1. Positive contact 2. Negative contact 8-10 mm crimping tool 2 Insert the crimped positive and negative cables into the corresponding photovoltaic connectors. 3. Positive connector



Make sure that the DC parameters of the strings are acceptable according to the technical specifications given in the datasheet and in the Azzurro ZCS configurator. In addition, **check that the polarities of the photovoltaic cables are correct**.







Use a MC4 wrench to disconnect the photovoltaic connectors



7. COMMUNICATION CONNECTION – COM PORT

Connections for master/slave mode:



lcon	Definition	Function	Note	
1	Link Port 1	Parallel Signal Output	Parallel Signal Port (RJ 45)	
2	Link Port 0	Parallel Signal Input		
3	Dip switch Link Port 1	Enables and disables the	The selector can be set to 0 (selector UP) or 1 (selector DOWN) A setting of 1 enables	
4	Dip switch Link Port 0	resistor	the resistor, while a setting of 0 disables it	

Port connection of COM communication:



PIN	Definition	Function	Remark
1	N/D	N/D	
2	UC-A	RS485 - A differential signal	Inverter monitoring signal 495
3	UC-B	RS485 - B differential signal	Inverter monitoring signal 465
4	EN+	RS485 + differential signal	Patton, signal 495
5	EN-	RS485- differential signal	Battery Signal 465
6	MET-A	RS485 - A differential signal	Intelligent counter signal 485
7	MET-B	RS485 -B differential signal	Intelligent counter signal 485
8	CAN-H	CAN high-speed data	CAN battony communication signal
9	CAN-L	CAN low-speed data	CAN battery communication signal
10	N/D	N/D	
11	N/D	N/D	
12	GND		
13	D1/5		(DRMS) Logical interfaces for Australia lower
14	D4/8	Logical interface signal	(DRIVIS) Logical Interfaces for Australia lower than standard (AS4777). Conoral Europa
15	D2/6	Logical interface signal	(FOE 40) Cormony (410E)
16	D0		(30349), Germany (4103)
17	D3/7		
18		Positive output terminal of	
	CT+	current transformer	Current transformer communication signal (CT)
19		Negative pole of current	Current transformer communication signal (CT)
	CT-	transformer output	
20	N/D	N/D	

8. BATTERY CONNECTION

Power connections up to 3 batteries (1 channel):

1

2

3

- Connect the **grounding** cables as shown in the figure.
- (BAT +, BAT -) of channel BAT 1 of the inverter connected in parallel to (B+, B-) of battery module 1.
- (B+, B-) of battery module 1 connected in parallel to (B+, B-) of battery module 2.
- (B+, B-) of battery module 2 connected in parallel to (B+, B-) of battery module 3.

Communication connections up to 3 batteries (1 channel):

- COM 1 of inverter → Link Port IN of battery module 1.
- Link Port OUT of <u>battery module 1</u> → Link Port IN of <u>battery module 2</u>.
- Link Port OUT of <u>battery module 2</u> → Link Port IN of <u>battery module 3</u>.
- Insert the terminating resistor on Link Port OUT of battery module 3.



Power connections up to 4 batteries (2 channels):

1

2

3

- Connect the **grounding** cables as shown in the figure.
- (BAT +, BAT -) of channel <u>BAT 1</u> of the <u>inverter</u> connected in parallel to (B+, B-) of <u>battery module 1</u>.
 (B+, B-) of <u>battery module 1</u> connected in parallel to (B+, B-) of <u>battery module 2</u>.

- (BAT +, BAT -) of channel <u>BAT 2</u> of the <u>inverter</u> connected in parallel to (B+, B-) of <u>battery module 3</u>.
- (B+, B-) of <u>battery module 3</u> connected in parallel to (B+, B-) of <u>battery module 4</u>.

Communication connections up to 4 batteries (2 channels):

- COM 1 of inverter → Link Port IN of battery module 1.
- Link Port OUT of <u>battery module 1</u> → Link Port IN of <u>battery module 2</u>.
- Insert the terminating resistor on Link Port OUT of battery module 2.

- COM 1 of inverter → Link Port IN of battery module 3.

- Link Port \overline{OUT} of battery module 3 \rightarrow Link Port IN of battery module 4.
- Insert the terminating resistor on Link Port OUT of battery module 4.



Note: Make sure the cable connections are firmly established.

For systems with a capacity exceeding 15 kWh, the batteries are connected in two independent groups to the inverter's battery input interface.

The battery capacity varies from 5 to 20 kWh (in the case of <u>4 batteries</u>, it is necessary to purchase the extension kit, code <u>ZZT-ZBT5K-EXT-KIT</u>).





When shutting down the system, ALWAYS DISCONNECT THE AC VOLTAGE by opening the designated switch. **NEVER SWITCH OFF the batteries before disconnecting the AC voltage**, and therefore with the storage system connected to the AC grid.

9.1 SETTING PHOTOVOLTAIC CHANNELS

To set the photovoltaic channels:

Basic settings → Channel configuration

When connecting strings in *independent mode*:

- Input channel 3 PV Input 1
- Input channel 4 PV Input 2

When connecting strings in parallel mode:

- Input channel 3 PV Input 1
- Input channel 4 PV Input 1

9.2 SETTING BATTERY CHANNEL

To set 1 battery channel:

Basic settings → Channel configuration

- Input channel 1 Batt Input 1
- Input channel 2 Not in use

Advanced settings →0715 → Battery parameters

- No. of batteries: Group 1 \rightarrow (enter the number of batteries installed) Group 2 \rightarrow 0

- Battery 1: Depth of discharge: 80% To set 2 battery channels:

Basic settings → Channel configuration

- Input channel 1 Batt Input 1
- Input channel 2 Batt Input 2

Advanced settings → 0715 → Battery parameters

- No. of batteries: Group 1 \rightarrow (enter the number of batteries installed) Group 2 \rightarrow (enter the number of batteries installed)

Battery 1:Depth of discharge: 80%Battery 2:Depth of discharge: 80%



10.1 MEASURING EXCHANGE VIA CT SENSOR



PIN	Definition
19	CT- (black/yellow)
18	CT+ (red)



Use for distances of less than 50 m between the inverter and CT

Connect negative and positive in the sensor respectively to inputs 19 and 18 of the COM connector

POSITIONING OF CT SENSOR:

 \checkmark <u>Positioned at the output of the import/export meter</u> so that all incoming and outgoing power flows can be read, it must include all phase cables entering or exiting the meter.

 \checkmark The *direction of the CT is independent of the installation*, and is recognised by the system during the first start-up.

Use an 8-pin, category 6 **STP** cable as an **EXTENSION CABLE**; use all the coloured pins (blue-orange-green-brown) to extend the positive cable of the CT and all the white/coloured pins (white/blue-white/orange-white/green/brown) to extend the negative cable of the CT. The shield must be grounded on one of the two sides.





10.2 MEASURING EXCHANGE VIA DDSU METER



PIN INVERTER	PIN METER	Note
6 —	→ 24	Communication of the Euchange Mater
7 —	→ 25	communication of the Exchange Meter



DDSU meter connections

1. Connect Meter and inverter via the RS485 serial port. On the Meter side, this port is identified by PINs 24 and 25.

On the inverter side, use the connection port identified as "COM" by connecting PINs 6 and 7.





- 2. Connect the Meter in "direct connect" mode, specifically:
- ✓ Connect PIN 2 of the Meter to the neutral cable (N);
- ✓ Connect PIN 3 respectively to the Exchange meter direction phase;
- ✓ Connect PIN 1 to the photovoltaic system and loads direction phase.

NOTE: For distances between the meter and hybrid inverter of more than 100 metres, it is recommended to connect two 120 OhM resistors along the 485 daisy chain: the first to the inverter (between PINs 6 and 7 of the inverter COM), the second directly to the meter (PINs 24 and 25).

10.2.1 DDSU METER SETTING ON EXCHANGE AND INVERTER

1. Press the 🔁 button to check that the Meter address is set to 001. In addition to what is described above, the display shows the values of:

- ✓ Current;
- ✓ Voltage;
- ✓ Power factor;
- ✓ Power.





Current



Power





2. To configure the Meter reading on the inverter, access the inverter display (as shown in the figure):

- 1. First button on the left of the inverter;
- 2. Advanced settings;
- 3. Enter password "0715";
- 4. Set PCC Meter;
- 5. Enable;
- 6. Ok.











Set PC	C Me	eter		



10.2.2 MEASURING EXTERNAL PRODUCTION VIA DDSU METER



DDSU meter connections

1. Connect Meter and inverter via the RS485 serial port.

On the Meter side, this port is identified by **PINs 24 and 25.**

On the inverter side, use the COM port by connecting **PINs 6 and 7**





- 2. Connect the Meter in "direct connect" mode, specifically:
- ✓ Connect PIN 2 of the Meter to the neutral cable (N);
- ✓ Connect PIN 3 respectively to the external production direction phase;
- ✓ Connect PIN 1 to the new photovoltaic system and loads direction phase.



NOTE: For **distances** between the Meter and hybrid inverter **greater than 100 meters**, it is recommended to connect two 120 Ohm resistors along the 485 daisy chain: the first to the inverter (between PINs 6 and 7 of the inverter COM), and the second directly to the Meter (PINs 24 and 25).



17

1.1 Press the button to check

that the Meter address is set to 002.

In addition to what is described above, the display shows the values of:

- ✓ Current;
- ✓ Voltage;
- ✓ Power factor;
- ✓ Power.









Address

Voltage

1.2 Production meter address setting:



2. No configurations are required on the inverter for the external production meter setting.





10.2.5 CHECKING CORRECT DDSU METER READING

In order to check the correct reading of the **meter on exchange**, turn off the hybrid inverter and any other PV production sources.

Switch on loads greater than 1 kW.

Stand in front of the meter and use the keys

" to scroll through the items, make sure that:

Power P is:

- •Greater than 1 kW.
- •In line with home consumption.
- •The sign in front of each negative value (–).



In the case of a **meter for reading the production of existing photovoltaic systems**, repeat the previous steps:

- 1. This time the sign of the powers must be positive for P.
- 2. Switch on the Hybrid Inverter, leaving the DC-side PV switch in the OFF position, check that the total external PV power value (Pt) is in line with the value shown on the inverter's display.

10.3 READING VIA DDSU METER

Single-line diagram of hybrid inverter with meter reading mode on exchange only



Single-line diagram of hybrid inverter with meter reading mode on exchange and external production





2. Connect PIN 10 of the Meter to the neutral wire (N), connect PINs 2, 5 and 8 to phases R, S and T respectively.
CT connections, the terminals of the sensor positioned on phase R must be connected to PIN 1 (red wire) and PIN 3 (black wire).
The terminals of the sensor positioned on phase S must be connected to PIN 4 (red wire) and PIN 6 (black wire).
The terminals of the sensor positioned on phase T must be connected to PIN 7 (red wire) and PIN 9 (black wire).
Position the sensors, paying attention to the direction on the sensor itself (arrow pointing towards the grid).
ATTENTION: hook the CT sensors to the phases only after connecting them to the Meter.

NOTE: For **distances** between the meter and hybrid inverter of **more than 100 metres**, it is recommended to connect two 120 OhM resistors along the 485 daisy chain: the first to the inverter (between PINs 6 and 7 of the inverter COM), the second directly to the meter (PINs 24 and 25).

PIN INVERTER	PIN METER	Note
6	→ 24	Materia
7	→ 25	Meter communication

DDSU METER SETTING ON EXCHANGE AND INVERTER

1. Press the button to check

that the Meter address is set to **001**.

In addition to what is described above, the display shows the values of:

- ✓ Current;
- ✓ Voltage;
- ✓ Power factor;
- ✓ Power.

2. To configure the Meter reading on the inverter, access the inverter display (as shown in the figure):

- 1. First button on the left of the inverter;
- 2. Advanced settings;
- 3. Enter password "0715";
- Set PCC Meter;
- 5. Enable;
- 6. Ok.

20

Ţ

10.3.1 SETTING DTSU METER

- To configure the device in read mode on the exchange, enter the settings menu as shown below: •Press **SET** and the word **CODE** will appear
- Press SET again
- •Enter the number "701":
 - 1. From the first screen where the number " $60\underline{0}$ " will appear, press the " \rightarrow " key once to write the number " $60\underline{1}$ ".
 - 2. Press "SET" twice to move the cursor left,
 - highlighting "<u>6</u>01";

3. Press the " \rightarrow " key once more to write the number "<u>7</u>01"

Note: In case of error, press "ESC" and then "SET" again to reset the required code.

•Confirm by pressing **SET** and to enter the settings menu.

•Enter into the following menus and set the parameters indicated:

- **1. CT**:
 - a. Press SET to enter the menu
 - b. Write "40":
 - a. From the first screen where the number "1" appears, press the " \rightarrow " key repeatedly until the number "10" is written.
 - b. Press **SET** once to move the cursor left, highlighting "10"
 - c. Press the " \rightarrow " key repeatedly until the number "40" is written.
 - d. Press "ESC" to confirm and " \rightarrow " to scroll to the next setting.



Note: In case of CT sensors other than those supplied, enter the correct transformation ratio.

Note: In case of error, press "SET" until the thousand digit is highlighted and then press "→" until only the number "<u>1</u>" is displayed; at this point, repeat the above procedure.

2. ADDRESS:

- a. Press **SET** to enter the menu:
- b. Leave "01" for Meter on exchange
- c. Write "02" (by pressing "→" once from screen "01"). With address 02, the inverter assigns the data sent by the meter as production power. A maximum of 3 meters can be set for the production (Addresses 02, 03 and 04)





Meter on Exchange

Meter on Production

d. Press "ESC" to confirm.

10.3.2 CHECKING CORRECT DTSU METER READING

In order to check the correct reading of the **meter on exchange**, turn off the hybrid inverter and any other PV production sources. Activate loads greater than 1 kW for each of the system's three phases. Stand in front of the meter and use the " \rightarrow " keys to scroll through the items, and "ESC" to go back, checking that:

 The Power Factor values for each phase Fa, Fb and Fc (representing the phase shift between voltage and current) fall within the range of 0.8 to 1.0. If the value is lower, move the sensor to one of the other two phases until the value falls within the specified range.

 The Pa, Pb and Pc Powers are: •Greater than 1 kW.

- •In line with home consumption.
- •The sign in front of each negative value (–).

In the case of a positive sign, reverse the direction of the toroidal winding in question.

For meters used to read the production of existing photovoltaic systems, repeat the previous steps as follows:

- 1. Check the Power Factor as described in the previous case.
- 2. This time, ensure that the sign of the powers (Pa, Pb, and Pc) are positive.
- 3. Switch on the Hybrid Inverter, and check that the total PV power value (Pt) matches the value displayed on the inverter's screen.







To supply DC voltage to the hybrid inverter, turn ON the circuit breaker

0.0

22

12. INITIAL SET-UP

IMPORTANT: Use a PC and a USB stick to perform any updates or adjust the country code settings.





Parameter	Note
1. Language option	The default setting is English.
*2. Setting and confirming system time	If the inverter is connected to the host computer as the App of the collector or for mobile devices, the time should have been calibrated to local time.
**3. Importing safety parameters	Find the safety parameters file (named after the corresponding country) on the website, download it onto the USB flash drive and import it.
***4. Setting battery parameters	Default values are shown according to the input channel configured
5. Set-up is complete	

*2. Importing and confirming system time





			1.Basio	c settin	gs				
							3. Safety	parame	ters
Coo	le		Region	Code	2	Re	gion		
	000		VDE4105		000		EN50438		
	001		BDEW	018	001	EU	EN50549		
000	002	Germany	VDE0126		002		EU-EN50549-HV		
0000		Germany		019	000	IEC EN61727			
	003		VDE4105-HV	020	000	Korea	Korea		
<u> </u>	004		BDEW-HV	021	001	Currelan	Korea-DASS		
	000		CEL016 Italia	021	000	0005050	FII General		
	001		CEPTOTOTAM	022	001	Europe General	EU General-MV		
001	002	Italia	CEI-021 External		002		EU General-HV		
	003		CEI-021 In Areti	024	000	Cyprus	Cyprus		
	004		CEI-021InHV		000		India		
				025	001	India	India-MV		
002	000		Australia		002		India-HV		
	008	Australia	Australia-B	026	000	Philippines	PHI		
	0.00		Australia C		001		PHI-MV		
<u> </u>	009		FSP-RD1699	027	000	New Zealand	New Zealand		
	001		RD1699-HV	027	002	New Zealand	New Zealand-HV		
003	002	Spain	NTS		000		Brazil		
	003		UNE217002+RD647		001		Brazil-LV		
	004		Spian Island	028	002	Brazil	Brazil-230		
004	000	Turkey	Turkey		003	03	Brazil-254		
005	000	Denmark	Denmark.		004		Brazil-288		
	001	-	DK-TR322		000	cll-i-	SK-VDS		
006	000	Greece	GR-Continent	029	001	PIOXARIA	SK-SSE		
	0001		Netherland	030	002		5K-25D		
007	001	Netherland	Netherland-MV	031-032	000				
	002		Netherland-HV	033	000	Ukraine			
008	000	Belgium	Belgium.	034	000	Norway	Norway	1	
	001	000000000	Relgium-HV		001	0000000	Norway-LV		N
009	000		G99	035	000	Mexico	Mexico-LV		CF
	001	06	698	036-037	000	(0)		\leftarrow	01
010	002		China-P	038	000	Insland ENE0429	Insland		co
0.00	001		Taiwan		000		Thai-PEA		
	002		TrinaHome	040	001	Thailand	Thai-MEA		
	003		HongKong	041					
	004	China	SKYWORTH	042	000	50Hz	LV-50Hz		
	005		CSISolar.	043					
	006		CHINT China MV	044	000	South Africa	SA		
	007		China-MV China-HV	045	001		SA-HV		
	000		China-A	045	000		DEWG		
	000		France	046	001	Dubai	DEWG-MV		
011	001		FAR Arrete23	047-106					
011	002	France	FR VDE0126-HV 107	107	000	Croatia	Croatia		
	003		France VFR 2019	108	000	Lithuania	Lithuania		
	000	Poland	Poland	109	000		┥────┤		
012	001		Poland-MV	110			Calumbia		
	002		Poland-HV Reland ARCD	111	000	Columbia	Columbia		
013	003	Austria	Tor Erzeugen	112-120	001		Columbia-LV		
0	000	Incound	- OT MLASMASS	121	000	Saudi Arabia	IEC62116		
014	001	Japan		122	000	Latvia			
015	003	Switzerlan.		123	000	Romania			
16-17					1				



To set the correct country, upload the unzipped folder called "safety" onto the USB flash drive. This folder can be downloaded from the website https://www.zcsazzurro.com/it/documentazione/ea sy-power-one-all

🗸 📩 Accesso rapido		Nome	Ultima modifica	Tipo	Dimensione
Desktop	*	safety	25/02/2022 16:54	Cartella di file	
🛓 Download	*	- I			
Documenti	*				
🔀 Immagini	*				
← → ~ ↑	•	Unità USB (D:) → safety			
\leftrightarrow \rightarrow \checkmark \uparrow	•	Unità USB (D:) → safety		_	
 ↔ → < ↑ ★ Accesso rapido 	•	Unità USB (D:) → safety	Ultima modifica	Tipo	Dimensione
 ← → < ↑ ★ Accesso rapido ■ Desktop 	*	Unità USB (D:) > safety Nom 000-000-0507	Ultima modifica 14/01/2021 02-41	Tipo Documento di testo	Dimensione 4 KB
 ← → · · ↑ ★ Accesso rapido ■ Desktop ↓ Download 	* *	Unità USB (D;) → safety Nom 000-000-0507 001-000-0507	Ultima modifica 14/01/2021 0241 06/01/2021 13:31	Tipo Documento di testo Documento di testo	Dimensione 4 KB 4 KB
 ← → < ↑ ★ Accesso rapido ■ Desktop ↓ Download I Documenti 	* * *	Unità USB (D;) > safety Nome 000-000-0507 001-000-0507 001-000-0507	Uttima modifica 14/01/2021 0241 06/01/2021 13:31 27/01/2021 13:31	Tipo Documento di testo Documento di testo	Dimensione 4 KB 4 KB
 ← → × ↑ ★ Accesso rapido Desktop ↓ Download Documenti ▲ Immagini 	* * *	Unità USB (D;) > safety Nom 000-000-0507 001-000-0507	Uttima modifica 14/01/2021 0241 06/01/2021 1331 27/01/2021 1027	Tipo Documento di testo Documento di testo Documento di testo	Dimensione 4 KB 4 KB 4 KB

NOTE: By default, the internal interface of the inverters are set to the CEI-021 country code, if a different country code is required, please contact technical support.

13. CHECKING THE CORRECT OPERATION

1) Turn OFF the PV circuit breaker and disconnect the inverter from the grid



2) Restore AC voltage by activating the dedicated switch:



3) Check that the power value shown on the grid display closely matches the power consumption shown on the meter, or measure using a current clamp under the import/export meter.

On-Grid S PV1 : NA PV	tate WF /2 : NA 1.47kW
+- 0.00kW	1.47kW
2018-06-28	09 : 11 : 28



5) Switch on the battery or batteries, ensuring that the system operates in the mode described in the section **OPERATING STATUSES IN AUTOMATIC MODE:**

- •PV>Load →battery charging
- •PV<Load Battery discharging
- •PV=Load Battery on stand-by





NOTE: At the initial start-up, the batteries will charge up to 100%



Note: If the conditions described above are not met:Check that the current sensor is correctly positioned and then proceed with restarting the system.



25

14. CHECKING THE INVERTER SETTINGS

To check whether the parameters have been correctly set, enter the display menu and go to "Inverter Info." Check the data, especially those highlighted:

Inverter Info (1) Serial Number: ZQ1025003KE233100073 Hardware version: V001 Software version: Press enter to view! Safety firmware version: V02000	 Serial number of the machine Hardware version Software version installed Service Code Version 	Inverter Info (4) IV Curve Scan : Disabled Logic interface: Disabled	 Information on MPPT scan mode Information on DRMs0 mode (enable only for Australia)
Inverter Info (2) Country: 001-000 Power level: 6 kW	➤Country code for the standard➤Max inverter power	Inverter Info (5) Power Factor : 1.00 Zero grid feed-in mode : Disabled Insulation resistance: 7000KOhm	 Power factor value Information on maximum grid in-feed mode Measured value of the insulation resistance
Inverter Info (3) PV Input Mode : Independent Working mode : Automatic mode RS485 address : 01 EPS : Disabled	 Photovoltaic input mode (Independer) Information on operating mode (mut) Communication address (value must) Information on EPS mode 	ent / Parallel) ist be automatic) t be different from 00)	

15. ZERO FEED-IN MODE





In the event of a power failure, or when operating in an OFF-Grid mode with the EPS function enabled, the HYD3000-HYD6000-ZP1 inverter will operate in Emergency Power Supply (EPS) mode using the PV power and energy stored in the battery to supply power to critical loads via the LOAD connection port.

17.2 EPS MODE (OFF GRID) - WIRING PROCEDURE AND INSTALLATION TYPES

Identify critical or priority household loads: it is advisable to identify household loads that are vital during power outages, such as lighting, refrigerators or freezers, emergency outlets.



• <u>High power loads</u> (such as ovens, washing machines, heat pumps) may not be supported by the inverter in EPS mode due to the maximum power that can be delivered under these conditions.

• <u>Loads with high inrush currents</u> (such as pumps, compressors or devices driven by electric motors) may not be supported by the inverter in EPS mode because their inrush current, even if only for a very short period, is considerably higher than that supplied by the inverter.

• <u>Inductive loads</u> (such as induction plates) may not be supported by the inverter in EPS mode due to their specific waveform requirements.

Connect the phase, neutral and ground wires to the LOAD output, located on the right side at the bottom of the inverter.

NOTE: the LOAD output must only be used for connecting the critical load.

CHANGE-OVER SWITCH

When performing maintenance on components of the photovoltaic system or when the inverter is unavailable for use, it is recommended to install a change-over switch. This switch allows the loads normally connected to the inverter's load line to be directly powered by the grid.





Position 1 \rightarrow Priority loads connected and powered by the inverter's LOAD line

Position 0 \rightarrow Priority loads not powered by the inverter or by the grid

Position 2 \rightarrow Priority loads connected and powered by the grid

DOUBLE SWITCH CONTACTOR

For subsidised systems, a double switch contactor can be installed. This device ensures that critical loads are normally powered by the grid, and they will only switch to the EPS LOAD line of the inverter in case of a power failure, thanks to the switching of the contactors.



NOTE: In the described conditions, during a power outage, the part of the system powered by the inverter's LOAD port operates in a manner similar to an IT system.

Note: If the hybrid inverter is to be installed under different conditions than those shown in the diagrams above, please contact technical support to check whether this is feasible.

17.3 EPS MODE (OFF GRID) - OPERATION

Under normal operating conditions with the alternating voltage supplied by the mains, both the system's standard loads and priority or critical loads are supplied directly by the mains, eliminating the need for a double switch-over contactor. This operation is shown in the figure below.

It should also be noted that the LOAD output remains powered at all times, even when the mains voltage is present.



During a **power outage**, the alternating voltage supplied by the grid will be lost. This condition will cause the internal contacts of the hybrid inverter to switch over. Once the preset activation time has elapsed, the inverter will continue to deliver a 230V alternating voltage to the LOAD output, supplying power only to critical loads according to the availability of the batteries and PV system.



NOTE: with this configuration, the system operates as an IT system during a power outage.

17.4 EPS MODE (OFF GRID) - MENU ENABLING

To enable the EPS (OFF-GRID) mode:

1. The EPS mode must be enabled from the display.

4

1. Battery parameters

t 4	1.Basic settings			
	₹.	5. Select EPS mode		
		4 4	1.EPS control mode	1.Enable EPS mode 🗸
2. The fo	bllowing parameters	s must be set from the	Depth of Discharge	1.Disable EPS mode
menu	2 Advanced settings			

3. Depth of discharge 💊



Activating the HYD3000-HYD6000-ZP1 inverter in off-grid mode allows it to supply power to the predefined critical loads using energy from the PV system and stored in the batteries. To do this, it is necessary to enable the EPS (Emergency Power Supply) mode.



- **18.2 OFF GRID MODE ONLY START UP**
- 1) Check that the DC circuit breaker of the inverter is in the OFF position.





2) Switch on the batteries:

Set the disconnect switch to ON;
 Press the button.

Once pressed, the button will light up and the internal contact will close.



3) Switch on the photovoltaic system by turning the switch to the ON position.



19.1 PARALLEL INVERTER MODE - CONFIGURATION



1. The inverters must be interconnected using the cable supplied, making sure to populate the inputs as follows: •Link port 0 of Master inverter with terminating resistor enabled (switch set to 1)

Link port 1 of Master Inverter → Link port 0 of Slave 1 Inverter
 Link port 1 of Slave 1 Inverter → Link port 0 of Slave 2 Inverter

•...

•Link port 1 of Slave n-1 Inverter → Link port 0 of Slave n Inverter

•Link port 1 of Slave n inverter with terminating resistor enabled (switch set to 1)

Note:

Terminating resistors can be enabled via a switch The parallel cable between inverters is supplied

- 2. If the inverters connected are of the same capacity, the LOAD outputs can be connected in parallel to supply power to the same group of priority loads. This requires the use of a parallel switchboard. It is necessary to ensure that the connections between each inverter and the parallel switchboard have:
- The same length
- The same cross-section
- The lowest possible impedance.

It is advisable to install appropriate protection for each connection line between the inverter and switchboard.

- 3. The combined load connected to the LOAD outputs should not exceed the total power output of the inverters in EPS mode.
- 4. The meters should be connected to the Master Inverter (Primary).



19.2 PARALLEL INVERTER MODE - SETTINGS

20. FIRMWARE UPDATE







To update the firmware, upload the unzipped folder called "Firmware" onto the USB flash drive. This folder can be downloaded from the website <u>https://www.zcsazzurro.com/it/documentazione/easy-power-one-all</u> The folder contains the files for the update in .bin or .hex format

		\leftrightarrow \rightarrow \checkmark \uparrow	\leftarrow \rightarrow \checkmark \uparrow 🗀 > Unità USB (D:) > firmware				
Nome	Ultima modifica Tipo Dimensione	Accesso rapido	Nome	Ultima modifica	Тіро	Dimensione	
Accesso rapido firmware Creative Cloud Files	22/09/2023 16:56 Cartella di file	Desktop 🦻	ESHV_ARM.bin	21/01/2022 04:06	File BIN	405 KB	
> 😻 Dropbox		Download	ESHV_DM.bin	24/01/2022 04:07	File BIN	146 KB	
> 📥 OneDrive - Personal		Immagini a	ESHV_DS.bin	20/01/2022 02:50	File BIN	118 KB	

21. SELF-TEST



23. QUICK INFO ON SYSTEM STATUS

Press **I** from the main menu to access the instant information on the battery and AC grid.

Vgrid:	· ··· 230. 2V
Igrid:	···· 7.85A
Frequency:	• 50.01Hz
Bat Voltage:	···· 48.2V
Bat CurCHRG:	···· 0.00A
Bat CurDisC:	···· 39.86A
Bat Capacity:	52%
Bat Cycles:	···· 0000T
Bat Temp:	····· 25°C

PV1	Voltage
PV1	Current 0.00A
PV1	Power OW
PV2	Voltage 7.1V
PV2	Current 0.01A
PV2	Power
Inve	erter Temp

Press from the main menu to access the instant information on the DC-side of the inverter.

24. OPERATING STATUSES IN AUTOMATIC MODE

When the power produced by the photovoltaic system is greater than the energy required by the loads, the inverter will charge the battery with the excess energy.

When the battery is fully charged, or when the charging power is limited (to preserve the integrity of the battery), the excess energy will be exported to the grid.

When the power of the photovoltaic system is once again less than the power required by the loads, the system will use the energy stored in the battery to power the household loads.

When the total power produced by the photovoltaic system and supplied by the battery is less than that required by the loads, the missing energy will be taken from the grid.

The inverter will remain in Standby mode until: •the difference between the photovoltaic production and the power required by the loads is less than 100W

•the battery reaches full charge status, and the photovoltaic production exceeds consumption by at least 100W)

•the battery is flat and the photovoltaic production is lower than consumption (by no more than 100W)