

FIRMWARE UPDATE AND SAFETY PARAMETERS

1. Buttons



- Press and hold the button to enter the menu and confirm your selection
- Press the button briefly to move to the next section
- Scroll through all menus to return to the home page

2. FIRMWARE UPDATE

1. Preparing the USB stick

1. Before changing the country standard, you must update the inverter firmware to the revision available on our website: www.zcsazzurro.com.
2. Select the inverter you are interested in and, in the documentation section, you can download the latest firmware, which is a zipped file containing a folder.
3. Unzip the file and extract the entire folder.
4. Copy the folder, without changing its name, to a USB stick (8GB) previously formatted in FAT32 format.

2. Update

1. Insert the USB stick into the appropriate port at the bottom of the inverter (with the inverter switched off).
2. Power the inverter from the photovoltaic source.
3. Select software update from the menu.
4. Enter the password -> 0715 and the update will start automatically.
5. Once the update is complete, switch off the inverter (by disconnecting it completely) and restart it to complete the operation.
6. Check under System Info -> Inverter Info -> Software Version "Press enter to view" -> 0715 and verify the updated version.

3. NETWORK STANDARD MODIFICATION

1. *Preparing the USB stick*

1. Download the required network standard from our website www.zcsazzurro.com.
2. Select the inverter of interest and in the documentation section you can download the safety standard, which is a zipped file containing a folder called "safety".
3. From these, select the txt file corresponding to the required network standard.
4. Copy the selected file to an empty folder named safety (written in lowercase letters).
5. Copy the folder to a standard USB stick (8GB) previously formatted in FAT32 format.

2. *Loading the network standard onto the inverter*

1. Insert the USB stick into the appropriate port located at the bottom of the inverter (with the inverter switched off).
2. Power the inverter only from a photovoltaic source (the operation will not be successful if the inverter is connected to the AC grid).
3. From the menu, select Settings -> Set country -> 0001.
4. Enter the password -> 0715 and select the country loaded on the USB stick from the display and wait for the confirmation message.
5. The parameters will be automatically loaded into the inverter memory.
6. Switch off the inverter (by completely disconnecting the power supply) and restart it to complete the operation.



ZUCCHETTI
Centro Sistemi



Identification: GID.GE.MD.00
Rev. 01 of 14.01.22 - Application: GID

Zucchetti Centro Sistemi S.p.A. - Green Innovation Division
Palazzo dell'Innovazione - Via Lungarno, 167
52028 Terranuova Bracciolini - Arezzo, Italy
tel. +39 055 91971 - fax. +39 055 9197515
innovation@zcscompany.com - zcs@pec.it - zcsazzurro.com

Reg. Pile IT12110P00002965 - Share capital €100,000.00 fully paid up
Company Reg. AR no. 03225010481 - REA AR - 94189
Certified Company
ISO 9001 - Certificate no. 9151 - CNS0 - IT-17778
ISO14001 - Certificate no. 1425 - CNSQ - IT-134812



Certificazione
sistema di gestione
ISO 9001
ISO 14001

