

FIRMWARE UPDATE AND SAFETY PARAMETERS

1. Buttons



- Long press the button to enter the menu and confirm the selection
- Short press the button to move to the next section
- Scroll through all the menus to return to the homepage

2. FIRMWARE UPDATE

1. Preparation of USB flash drive

1. Before changing the standard country, it is necessary to update the inverter firmware to the version present on our website: www.zcsazzurro.com.
2. Select the relevant inverter and in the documentation section, download the latest firmware, which comes in a zipped file containing a folder.
3. Unzip the zipped file and extract the entire folder.
4. Copy the folder without changing its name onto a USB flash drive (8 GB) previously formatted in FAT32 format.

2. Updating

1. Insert the USB into the appropriate port at the bottom of the inverter (with the inverter switched off).
2. Power up the inverter from a photovoltaic source.
3. Select "Software Update" from the menu.
4. Enter the PWD -> 0715 and the update will start automatically.
5. When the update is complete, switch off the inverter (disconnect it completely) and restart to finish the update.
6. Go to system info -> Inverter info -> Software Version "Press enter to view" -> 0715 and check for the updated version.

3. NETWORK STANDARD MODIFICATION

1. Uploading of network standard to the inverter

1. Power up the inverter from a photovoltaic source only (the operation will fail if the inverter is connected to the AC grid).
2. From the menu, select settings -> Set country -> 0001.
3. Enter the PWD -> 0001 and select the country from the display. Wait for the confirmation message.
4. Switch off the inverter (disconnect it completely) and restart it to complete the operation.